



VARILIGHT V-Pro
Dimmerswitches

PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE	J_P
Please record the batch number printed on the side of the plastic moulding on the rear of the product. This will assist us in providing any technical support you may require.	
BATCH NO:	Reg. 758B

Thank you for choosing a **VARILIGHT V-Pro** intelligent trailing-edge dimmerswitch. Use only on an electricity supply of 200-250V a.c.

This dimmerswitch features **V-Pro intelligent load detection** which enables it to adapt to many different types of lighting load. When the dimmer is switched on it will detect the load and adjust its dimming pattern accordingly. Should you decide to change your lighting at some time in the future, please follow the instructions for "Resetting the dimmer" at the bottom of this page.

This product complies with European Safety Regulations (IEC 669-2-1 or BSEN 60669-2-1) when used in lighting circuits containing MCBs (miniature circuit breakers). These can be rated at 6A, 10A or 16A (preferably 6A for lighting circuits). Your guarantee is not affected if you have an older lighting circuit protected by fuse wire links.

THIS SWITCH IS SUITABLE FOR

- ✓ Mains voltage incandescent GLS or candle-shaped bulbs;
- ✓ Good quality dimmable electronic low voltage transformers (including those requiring trailing-edge control) [see "Transformers" box on the right];
- ✓ GU10 or similar good quality mains halogen bulbs.
- ✓ Dimmable CFLs
- ✓ Most dimmable LEDs [see "Dimmable LEDs" box on the right]

Always observe the recommended maximum load
[see "Overload Protection" box on the right]

THIS SWITCH IS NOT SUITABLE FOR

- ✗ Non-dimmable fluorescent bulbs and tubes;
- ✗ Wire-wound or toroidal transformers;
- ✗ Electric motors.

FITTING YOUR DIMMERSWITCH:

Read the instructions below carefully. Incorrect installation may damage the dimmer beyond repair. **In case of any doubt or difficulty consult a qualified electrician.**

1. Switch off at the mains, then remove the existing switch and disconnect the wiring from the switch terminals at the rear, taking note of the present wiring of the switch and the marking on the terminals. Where there are two or more wires together in the old switch, they must be kept together in the dimmerswitch.
2. Ensure that any wall box is free of plaster lumps or projecting screw heads. Dimmerswitches on single-sized plates can be fitted to wall boxes having 60.3mm screw fixing centres and those with double-sized plates to wall boxes with 120.6mm fixing centres. Most models can be fitted into a box with a minimum depth of 25mm. A box having 4 fixing lugs cannot be used without modifying it. The top and bottom lugs must be broken off or bent flat.
3. To connect the wiring for 1-way or 2-way circuits refer to the diagrams overleaf under the heading "Typical Lighting Circuits". Take care that no bare wires project out of the terminals. Keep wires together in a terminal if they were together in your old switch.
4. Dimmerswitches having a metal front plate must be earthed by means of the earthing point on the dimmer.
5. After connecting the wires screw the dimmerswitch gently into the wall box so that the front plate is not distorted or cracked. Do not trap the wiring between the rear of the dimmer and the back of the wall box.
6. Once installation is complete. Switch on the mains supply and switch on the dimmer, turning the control knob to give the desired light level.

OPERATING YOUR DIMMERSWITCH

When you first install the dimmer switch it will automatically detect your lights and determine the best way to control them. You may be able to improve the dimming performance of some types of lighting by adjusting the dimmer settings as follows. (You may also need to refer to this section if you change your lights to a different type at a later date so please keep these instructions for reference).

Adjusting the minimum brightness

If your lights are flickering when they are dimmed to a low level you can increase the minimum brightness setting of the dimmer, which may prevent this from happening. If the lights are brighter than you would like when the dimmer is set to minimum, you can try reducing the minimum brightness setting of the dimmer.

1. Switch on and set the dimmer knob to the MINIMUM position (turn fully anti-clockwise).
2. Turn the lights off and back on again. OFF – ON. Wait until the lights come on.
3. Repeat step 2 at least twice more. OFF – ON – OFF – ON, waiting until the lights come on each time they are switched on.
4. The lights will step up and down in brightness to show that the dimmer is in CONFIGURATION MODE, then go off.
5. Turn the knob fully clockwise. The lights will come on and allow you to adjust the minimum brightness.
6. Adjust the brightness that you are happy with as the minimum. Leave the dimmer in this position.
7. After 3 seconds the dimmer will notice that you have stopped adjusting the minimum. The lights will step up and down in brightness to show that the dimmer has returned to normal operation.
8. Continue to use the dimmer as normal, with your new minimum brightness.

Changing the driving mode

You may be able to improve the performance of your lamps by manually selecting the driving mode.

1. Switch on and set the dimmer knob to the MAXIMUM position (turn fully clockwise).
2. Turn the lights off and back on again. OFF – ON. Wait until the lights reach full brightness.
3. Repeat step 2 at least twice more. OFF – ON – OFF – ON, waiting until the lights reach full brightness each time they are switched on.
4. The lights will step up and down in brightness to show that the dimmer is in CONFIGURATION MODE, then go off.
5. Turn the knob fully anti-clockwise. The dimmer will change the mode of driving your lights.
6. The lights will FLASH ONCE or TWICE to show which mode the dimmer is in, then go off.
7. Turn the switch off. When you turn it on, the dimmer will continue to use the new mode.

Resetting the dimmer

If you change your lights it is recommended that you reset the dimmer so that it can calculate the optimum settings for the new lights. You can reset the dimmer to the factory default minimum settings and re-launch auto load detection as follows.

1. Switch on and set the dimmer knob to the MAXIMUM position.
2. Turn the lights off and back on again. OFF – ON. Wait until the lights reach full brightness.
3. Repeat step 2 at least twice more. OFF – ON – OFF – ON, waiting until the lights reach full brightness each time they are switched on.
4. The lights will step up and down in brightness to show that the dimmer is in CONFIGURATION MODE, then go off.
5. Within 5 seconds, repeat steps 2 and 3. OFF – ON – OFF – ON – OFF – ON, waiting until the lights reach full brightness each time they are switched on.
6. The dimmer will reset all its settings to factory defaults. The lights will come on, then fade away to off.
7. The load auto-detection will determine the best way to drive your lights and FLASH ONCE or TWICE to show which mode it has chosen.
8. Continue to use the dimmer as normal.

OVERLOAD PROTECTION:

This dimmerswitch is protected against overload. If an overload occurs it will **automatically turn off** until the overload is removed and the dimmerswitch is switched off and then switched back on again. If the dimmerswitch receives a total short-circuit it may cease to function. (In this case return the unit to our service department at the address below and not to your supplier. The service department will repair your dimmerswitch free of charge. See guarantee overleaf.)

TRANSFORMERS:

Use only with quality dimmable **electronic** transformers. For optimum performance choose VARILIGHT transformers. Do **not** use with wirewound or toroidal transformers.

To calculate load, add the VA ratings of the **transformers (not the wattage of the bulbs)**. Choose transformers with a maximum rating close to their lamp load (e.g. Use a 50VA, 60VA or 70VA transformer to control a 50W low voltage bulb).

N.B. Certain transformers **may not behave according to their power rating when used with a dimmer**. An overload will result in the safety features switching the dimmer off. If so, change your transformer(s) (VARILIGHT transformer(s) recommended); or remove one (or some) transformer(s) from the circuit; or choose a higher rated dimmer.

DIMMABLE LEDs

The minimum load per gang is 10W. Always choose LEDs that are "dimmable" and for the best performance choose dimmable LEDs from established brands. We cannot guarantee that all LEDs labelled as "dimmable" can actually be dimmed satisfactorily. The **maximum load of dimmer should be de-rated** for LEDs. Check www.varilight.co.uk/led for latest advice on loading.

Maximum and minimum loads will vary according to make and type of LED. Refer to LED manufacturer for specific loading information. If in doubt, use 2 to 10 lamps per gang (or 100W, whichever is lower).

TYPICAL LIGHTING CIRCUITS

Your VARILIGHT intelligent trailing-edge dimmerswitch is suitable for 1-way or 2-way lighting circuits. It has a push on/push off action to switch and a rotary action to dim. There are 3 screw terminals per module.

1-WAY CIRCUITS


In 1-way lighting circuits each light is controlled by one switch. Your dimmerswitch should replace this switch. See Figure 1. Remove your old switch and copy the wiring configuration for your dimmerswitch. Connect wires either way round to the 'C' terminal and one of the 'L' terminals. The other 'L' terminal is not used in a 1-way circuit.

To fit 2 gang (or 3 or 4 gang) dimmerswitches treat each group of terminals at the back of the unit as a separate dimmerswitch wiring them into the lighting circuits as described above. If required, one terminal from each dimmer module may be joined together with a short length of wire to copy the wiring configuration of the old switch.

Typical 1-way Circuits

(For single dimmerswitches or each module of a multi-gang dimmerswitch)

Figure 1. Using a 1 or 2-way Dimmerswitch



2-WAY CIRCUITS

2-way lighting circuits have two switches turning the same lights on and off from 2 different locations (eg. at the top and bottom of the stairs). You must only replace **one** of these switches with a dimmerswitch or the lights will flicker. See Figures 2 and 3 which show typical 2-way circuits. Remove your old switch and copy the wiring configuration for the dimmer.

The wire(s) fitted in the "common" terminal of the old switch should be fitted into the "C" terminal of the dimmerswitch. The wires fitted into the other two terminals of the old switch should be fitted either way round into terminals "L1" and "L2" of the dimmerswitch.

Typical 2-way Circuits

(For single dimmerswitches or each module of a multi-gang dimmerswitch)

Figure 2. Using a 2-way Dimmerswitch. Dimmer must replace only one of the 2-way switches





Figure 3. Using a 2-way Dimmerswitch. Dimmer must replace only one of the 2-way switches



GUARANTEE

In case of any defect, return the dimmer to our service department. Varilight undertakes to repair or replace, at its discretion, goods which have become defective within 12 months of purchase, solely as a result of faulty materials and workmanship, provided that:-

- The unit has been correctly fitted according to the instructions and has not been used with an incompatible load, fluorescent tubes, or overloaded beyond its rating, and has only been used on a 200-250V a.c. power supply.
- The dimmer module has not been tampered with or taken apart. However, for your convenience, it is perfectly in order to remove a faulty dimmer module from multi-gang dimmers by pulling off the knob and unscrewing the nut under the knob. You will then still have the remaining modules working whilst we service your faulty module.
- The unit is securely packed and safely returned to:-

Service Department, Carylls Lea, Faygate, Horsham, West Sussex, RH12 4SJ (Tel. (01293) 851584) together with a letter stating the guarantee registration number below, the date and place of purchase, the type and wattage of the lighting or other load being controlled and the details of the fault.

This guarantee states Varilight's entire liability, which does not extend to cover consequential loss or damage or installation costs arising from a defective product. The guarantee does not apply to problems arising from any incompatibility between your lamps and the dimmer switch. This guarantee does not in any way affect the statutory rights of the purchaser and is offered so that you may have the benefit of our technical facilities.

GUARANTEE REGISTRATION NUMBER: 758B